Versie : 1.1
Datum : 06 januari 2026

OIL LEAK STOP

Features
UTB Oil Leak Stop revitalises and restores engine seals. It is added to the engine oil to recondition rubber gaskets, effectively stopping and preventing oil leaks. Suitable for all petrol and diesel engines with minor leaks and fully compatible with all common engine oils. For troubleshooting and preventive maintenance to minimise oil consumption and keep the engine bay clean:

- Revitalises rubber seals and gaskets
- Helps to significantly reduce oil consumption
- Suitable for all petrol and diesel engines

Applications
Add UTB Oil Leak Stop to a warm engine and then drive as normal. Results will become noticeable after several hundred kilometres. Note: not suitable for engines with serious mechanical defects.

Volume	Art.no.
24 x 250 ml	7200424250

UTB LUBRICANTS B.V.

Kamerlingh Onnesweg 28
3316 GL Dordrecht
The Netherlands

T: +31(0)88 - 0202300
F: +31(0)88 - 0202399
I: www.utb.nl
E: info@utb.nl

Vermelde productwaarden zijn indicatieve typische waarden. UTB BV kan niet aansprakelijk worden gehouden voor eventuele druk- of zetfouten. Op al onze transacties zijn onze algemene leverings- en verkoopvoorwaarden van toepassing.
Mentioned product values are indicative typical values. UTB BV can not be held responsible for any printing or typographical errors. On all our transactions our general delivery and sales conditions apply.